


PKZ 2 Manual Motor Protectors Dimensions


Manual motor protector, trip blocks

PKZ2/(Z)M-...,
ZMR-...-PKZ2




Trip-indicating auxiliary contact

AGM 2-11-PKZ2




Standard auxiliary contact

NHI...PKZ2




Remote control drive

RE-PKZ2 (...)
RS-PKZ2 (...)



Voltage trips


U-PKZ2 (...)
A-PKZ2-...



PKZ 2 Manual Motor Protectors and Motor Protector Combinations Dimensions


High-capacity magnetic motor protector combination

PKZ2/ZM-.../S(-SP)
PKZ2/ZM-.../S-G




Standard auxiliary contacts for high-capacity magnetic motor protector combination

NHI...S-PKZ2




S(-G) high-capacity contact modules CL current limiters

Type -G only




EZ base for separate mounting

HI11-S/EZ standard auxiliary contact for EZ separate mounting




Enclosure for surface mounting


C119EE-PKZ2-NA




CS3-PKZ2



C143X-150-PKZ2-SP




GKP23-PKZ2




PKZ 2 Manual Motor Protectors and Motor Protector Combinations

Dimensions


Door coupling handle
(R)H-PKZ2




Three-phase feeder bus connector
B3.1/3-PKZ2




B3.1/2-PKZ2





Terminal
BK50/3-PKZ2



Cover for unused terminals
HB-3-PKZ2




Mechanical interlock for high-capacity contactor modules
MV-PKZ2



Component adapters

AD40/5(10)-1



AD40/5(10)-2

